


# Parts Breakdown



# Parts List

REF	PART #	DESCRIPTION
1	P0479001	ADJUSTING NUT
2	P0479002	CLAMPING LEAF
3	P0479003	T-NUT M10-1.5
4-1	P0479004-1	1-1/2" FINGER
4-2	P0479004-2	2" FINGER
4-3	P0479004-3	3" FINGER
4-4	P0479004-4	4" FINGER
5	PSB61M	CAP SCREW M10-1.5 X 20
6	P0479006	CLAMPING BLOCK
7	P0479007	ADJUSTING NUT SPRING
8	PW13M	FLAT WASHER 20MM
9	P0479009	GREASE FITTING 8MM
10	P0479010	BUSHING
11	PW23M	FLAT WASHER 30MM
12	P0479012	FOLDING LEAF PIN
13	P0479013	STOP COLLAR
14	PSB84M	CAP SCREW M10-1.5 X 35
15	PN02M	HEX NUT M10-1.5
16	PSB47M	CAP SCREW M10-1.5 X 40
17	P0479017	LEG
18	PR11M	EXT RETAINING RING 25MM
19	P0479019	LEG PIN
20	PSB72M	CAP SCREW M10-1.5 X 30
21	P0479021	EXTENSION BRACKET
22	P0479022	DISC SPRING
23	P0479023	ROD
24	P0479024	FOOT PEDAL LEVER
25	P0479025	LEVER PIN
26	P0479026	FOOT PEDAL

REF	PART #	DESCRIPTION
27	P0479027	TREAD PLATE RUBBER
28	PR01M	EXT RETAINING RING 10MM
29	P0479029	PEDAL LOCK PIN
30	PW01M	FLAT WASHER 8MM
31	P0479031	PEDAL LOCK SPRING
32	PRP79M	ROLL PIN 8 X 50
33	P0479033	FOOT PEDAL LOCK
34	PRP33M	ROLL PIN 6 X 50
35	PRP80M	ROLL PIN 10 X 50
36	P0479036	O-RING 33 X 25
37	P0479037	SETBACK SHAFT
38	PB87M	HEX BOLT M8-1.25 X 15
39	P0479039	SETBACK KNOB
41	P0479041	BENDING LEAF
43	P0479043	BENDING LEAF PLATE
44	P0479044	SHIM RING
45	P0479045	CAM
46	P0479046	HEX BOLT M12-1.75 X 150
47-1	P0479047-1	BENDING LEAF 1-1/2" FINGER
47-2	P0479047-2	BENDING LEAF 2" FINGER
47-3	P0479047-3	BENDING LEAF 3" FINGER
47-4	P0479047-4	BENDING LEAF 4" FINGER
48	PTLW12M	EXT TOOTH WASHER 12MM
49	P0479049	BOTTOM STRUT
50	P0479050	COMPRESSION SPRING
51	P0479051	SPIRAL BLOCK
52	P0479052	TOP STRUT
53	P0479053	BUSHING

