

G1028Z Parts List

REF	PART #	DESCRIPTION
1	P1028001	CASTER
2	PFB01	FLANGE BOLT 5/16-18 X 1/2
4	P1028004	BASE PLATE
5	PS06	PHLP HD SCR 10-24 X 3/8
6A	P1029006A	6" INLET COVER V2.10.01
7	PSB121M	CAP SCREW M6-1 X 20 (LH)
8	PB09	HEX BOLT 5/16-18 X 1/2
9	P1028009	SPECIAL WASHER
10	P1028Z010	11" IMPELLER
11	P1028011	COLLECTOR BODY
12	PW07	FLAT WASHER 5/16
14	PFB01	FLANGE BOLT 5/16-18 X 1/2
15	PB03	HEX BOLT 5/16-18 X 1
16	PSW04	PUSH BUTTON SWITCH (G1028/29/30)
17V2	P1028Z017V2	MOTOR 1-1/2HP 110/220V V2.06.08
17V2-1	P1028Z017V2-1	MOTOR FAN COVER V2.06.08
17V2-2	P1028Z017V2-2	MOTOR FAN V2.06.08
17V2-3	P1028Z017V2-3	CAPACITOR COVER V2.06.08
17V2-4	P1028Z017V2-4	S CAPACITOR 300M 125V 1-3/4 X 3-3/8
17V2-5	P1028Z017V2-5	JUNCTION BOX V2.06.08
18	PN02	HEX NUT 5/16-18

REF	PART #	DESCRIPTION
19	P1028019	OUTLET
20	P1028020	HOSE CLAMP
21	P1028021	HOSE
22A	H6899	LOWER BAG V2.1.08
23	P1028023	COLLECTOR SUPPORT
24	P1028024	COLLECTOR
25	P1028025	PACKING (G1028Z)
26	P1028026	UPPER BAG SUPPORT
27A	G5556	UPPER BAG V2. 1.08
28	P1028028	GASKET
29A	P1029029A	INLET CAP 6"
29B	P1029029B	6"x4"x4" Y-INLET V2.10.01
30	PK32M	KEY 6 X 6 X 28
31	PWRCRD220S	POWER CORD
34	PWRCRD220L	MOTOR CORD
38A	G3707	CLAMP V2. 1.08
40	P1028Z040	ELECTRICITY LABEL
41	P1028Z041	HANDS/OUTLET LABEL
42	P1028Z042	READ MANUAL LABEL
43	P1028Z043	MACHINE ID LABEL
44	P1028Z044	EYE/LUNG LABEL

G1029Z Parts List

REF	PART #	DESCRIPTION
1	P1028001	CASTER
2	PFB01	FLANGE BOLT 5/16-18 X 1/2
4	P1028004	BASE PLATE
5	PS06	PHLP HD SCR 10-24 X 3/8
6A	P1029006A	6" INLET COVER V2.10.01
7	PSB121M	CAP SCREW M6-1 X 20 (LH)
8	PB09	HEX BOLT 5/16-18 X 1/2
9	P1028009	SPECIAL WASHER
10	P1029010	12" IMPELLER
11	P1028011	COLLECTOR BODY
12	PW07	FLAT WASHER 5/16
14	PFB01	FLANGE BOLT 5/16-18 X 1/2
15	PB03	HEX BOLT 5/16-18 X 1
16	PSW04	PUSH BUTTON SWITCH
17V2	P1029017V2	MOTOR 2 HP 220V V2.06.08
17V2-1	P1028Z017V2-1	MOTOR FAN COVER V2.06.08
17V2-2	P1028Z017V2-2	MOTOR FAN V2.06.08
17V2-3	P1028Z017V2-3	CAPACITOR COVER V2.06.08
17V2-4	P1028Z017V2-4	S CAPACITOR 400M 125V 1-3/4 X 3-3/8
17V2-5	P1028Z017V2-5	JUNCTION BOX V2.06.08
18	PN02	HEX NUT 5/16-18

REF	PART #	DESCRIPTION
19	P1028019	OUTLET
20	P1028020	HOSE CLAMP
21	P1028021	HOSE
22A	H6899	LOWER BAG V2.1.08
23	P1028023	COLLECTOR SUPPORT
24	P1028024	COLLECTOR
25	P1029025	PACKING
26	P1028026	UPPER BAG SUPPORT
27A	G5556	UPPER BAG V2. 1.08
28	P1028028	GASKET
29A	P1029029A	INLET CAP 6"
29B	P1029029B	6"x4"x4" Y-INLET V2.10.01
30	PK28M	KEY 7 X 7 X 29
31	PWRCRD220S	POWER CORD
34	PWRCRD220L	MOTOR CORD
38A	G3707	CLAMP V2. 1.08
40	P1029Z040	ELECTRICITY LABEL
41	P1029Z041	HANDS/OUTLET LABEL
42	P1029Z042	READ MANUAL LABEL
43	P1029Z043	MACHINE ID LABEL
44	P1029Z044	EYE/LUNG LABEL